MAIN SPINDLE ASSEMBLY

FRONT BEARING HOUSING
PART NO.: 0101

LOCK NUT
PART NO.: 0102

COVER PLATE FRONT
PART NO.: 0103

SPACER RING
PART NO.: 0104

SPINDLE NOSE CAP
PART NO.: 0105

MAIN SPINDLE
PART NO.: 0106

SPINDLE PULLY
PART NO.: 0107

SPACER BUSH BIG & SMALL
PART NO.: 0108 & 109

REAR BEARING HOUSING
PART NO.: 0110

COVER PLATE REAR
PART NO.: 0111

RING NUT
PART NO.: 0112

CHUCK LEVER BEARING
PART NO.: 0113

MAIN SPINDLE ASSEMBLY

CHUCK LEVER SLEEVE
PART NO.: 0114

ADJUSTING RING NUT
PART NO.: 0115

COLLERT SLEEVE
PART NO.: 0116

COLLET PUSHER TUBE
PART NO.: 0117

COLLET SPACER TUBE
L-20, L-22, L-25, L-27, L-33, L-37
PART NO.: 0118, 0121,0122

RING FOR FRONT BEARING HOUSING
PART NO.: 0119

SPINDLE OIL FLASH COVER
PART NO.: 0120

COLLET SPRING

REDUCTION COLLET SLEEVE A25/32

REDUCTION NOSE CAP
A32/25, A42/25, A60-25

SPINDLE SLEEVE

SPACER RING